



ELEVATION

NOTES:

1. LATERAL MATERIAL TO MATCH SEWER MAIN MATERIAL.
2. TRACER WIRE SHALL BE INSTALLED CONTINUOUSLY FROM THE MAIN TO THE RIGHT-OF-WAY LINE DIRECTLY ON TOP OF THE PVC LATERAL, ATTACHED EVERY 10 FEET.

## DEEP SANITARY SEWER SERVICE CONNECTION

NOT TO SCALE